

STUDIO SELECT - HOW TO ORDER

1 - CHOOSE











4 - CHOOSE **YOUR TYPE**





Studio Select Types

Note: 2 Numerical Digits after the dash are our numbers for Sofa, Loveseat, etc.

- 73 Sofa 75" 3 over 3
- 53 Sofa 75" 2 over 2
- 83 Sofa 80" 3 over 3
- 63 Sofa 80" 2 over 2
- 86 Sofa 85" 3 over 3
- 66 Sofa 85" 2 over 2
- 55 Loveseat
- 84 Chair
- 80 Ottoman
- 31 LAF Loveseat
- 32 RAF Loveseat
- 33 Armless Loveseat
- 34 Quarter Round
- 37 Armless Chair
- 38 RAF Sofa 3 over 3
- 39 LAF Sofa 3 over 3
- 41 LAF Chaise
- 42 RAF Chaise
- 43 LAF Corner Sofa 3 over 3
- 44 RAF Corner Sofa 3 over 3





YOUR ARM

2 - CHOOSE

YOUR BACK











E - TIGHT BACK







5 - CHOOSE

6 - ADD **TOP-STITCH** (Removes Welt option charges apply)



3 - CHOOSE YOUR BASE







7 - HOW TO **ORDER**

YOUR

SEAT STYLE

Sock Arm (A), Box Semi Attached Back (D), Wood Turned Foot (C), then sku item number,

for a 75" sofa (-73), followed by (T) for T-cushion Final sku would be: ADC-73T Sofa


Note: All Kincaid Custom upholstery finishes are available on exposed wood legs.




STUDIO SELECT - PRODUCT TYPES







EXAMPLE: For the sofa shown right - the order would be:



-73 75" Sofa Overall Dimensions: W 75 X D 36 X H 36


-83 80" Sofa Overall Dimensions: W 80 X D 36 X H 36

-86 85" Sofa Overall Dimensions: W 85 X D 36 X H 36

-53 75" Sofa Overall Dimensions: W 75 X D 36 X H 36

-63 80" Sofa Overall Dimensions: W 80 X D 36 X H 36


-66 85" Sofa Overall Dimensions: W 85 X D 36 X H 36




-55 Loveseat Overall Dimensions: W 54 X D 36 X H 36



-84 Chair Overall Dimensions W 34 X D 36 X H 36



-80 Ottoman Overall Dimensions: W 26 X D 19 X H 18



-31 LAF Loveseat Overall Dimensions: W 48 X D 36 X H 36




-32 RAF Loveseat Overall Dimensions: W 48 X D 36 X H 36



-33 Armless Loveseat

Overall Dimensions: W 41 X D 36 X H 36


Note: Sizes vary depending on arm style used - See associate.




-34 Quarter Round Overall Dimensions: W 62 X D 39 X H 36



-37 Armless Chair



-38 RAF Sofa - 3 over 3 Overall Dimensions: W 68 X D 36 X H 36




-39 LAF Sofa - 3 over 3




-41 LAF Chaise Overall Dimensions: W 28 X D 57 X H 36



-42 RAF Chaise



-43 LAF Corner Sofa Overall Dimensions: W 84 X D 36 X H 36



-44 RAF Corner Sofa Overall Dimensions: W 84 X D 36 X H 36